Melt Pressure Transmitter

Model: PT124B-121 (Flexible stem)

ZHYQ

Description

PT124B-121 Series Melt Pressure Transducer (Flexible stem), This series can be utilized together with the PY Series Intelligent Digital Pressure Instrument. Zero & full span can be adjustable, amplify signal output can be connected with PLC, with advantages of high precision and reliable pressure measuring and good quality and internal 80% calibration.

Application


- Chemical fiber Equipment
- Plastic and Rubber manufacturing equipment
- Medicine & Food process equipment
- Measurement and Control all kinds of melt fluid

Feature

- Stainless steel welding
- Easy to install
- Zero and span adjustable
- Various amplified signals optional
- Internal 80% shunt calibration
- Good stability and anti-jamming capability
- Excellent stability and repeatability

Dimension







Specification	
Pressure range:	03.5 MPa to 0150MPa
Output:	0~5V; 0~10V; 4-20mA;
Input voltage:	24 (12~36V) DC
Accuracy:	±1.0%FS ; ±1.5%FS (including linearity , Repeatability & Hysteresis)
Repeatability:	±0.2% FSO
Construction:	Wheatstone bridge
Bridge resistance:	Input: 345 Ohms Minimum; Output: 350 Ohms±10%
Overload pressure:	1.5×FSO
Internal shunt calibration:	80%±1%
Insulation Resistance:	200Megohms @100Vdc
Standard wetted Parts	Diaphragm coated 15-5PH SST
Mounting Torque	500inch/lbs , maximum
Max. Diaphragm Temp:	0~400 ℃
Electronic operating temperature:	-25℃ -85℃
Electric connector:	5PIN ,6 PIN
Rigid Length:	6",9" (Customer design)
Flexible Length:	18", 30" (Customer design)
Process connection:	1/2"-20UNF, M14×1.5, M18×1.5 (Customer design)

Mounting Hole

	D1	M22×1.5	M28×1.5	G3/4″	PT3/8″
	D2	Ф16.1	Ф18.3	Ф18.3	Ф10.3
	D3	Ф20.1	Ф26.1	Ф24.2	Ф14.9
	М	Ф23	Ф30	Φ21	Φ11
	А	11	12	12	14
C B	В	12	15	15	19
Planar Sealed	С	40	35	35	40
	D1	M12×1.5	M14×1.5	1/2-20UNF	M18×1.5
STITITI S	D2	Ф8	Ф8	Ф8	Ф10.1
	D3	Ф10.8	Φ12.5	Φ11.5	Ф16.1
	D4	Φ12.5	Φ14.5	Φ13.1	Ф20
	А	6	6	6	6.5
45° Slope Sealed	В	9	9.5	9.5	10

Ordering Guide

Model	Range (bar)	Output	Rigid & flexible length (inch)	Screw Thread	Electric connection	Accuracy	Others
PT124B-121							
Example: PT	124B-121-50	0Bar-4-2	0mA -6/18"-1/2-20	UNF-6PIN	-1.0%FS		

Attention for installation

1, Installation

Do not remove protective cap until ready to install. Prior to initial installation, verify correct machining of mounting hole. Install with aluminum gasket. The electronics housing should be secured, with the enclosed mounting bracket.

2, Remove

Make sure that there is no remained metal or plastic; remove all of the transducers from the equipment before you clean the extruder. You can remove the transducer only when the polymer is molten. And clean the diaphragm of the transducer with soft cloth as soon as you remove it. At the same time, you can use ZHYQ's cleaning tool kit to clean the remained material in the mounting hole in order to install easily next time.

3, Start-up

Bring system to operating temperature, and with no pressure, follow recommended procedures with instrumentation for zero and span adjustment. Make sure that there is sufficient "soak time" to assure that any material at the tip of the transducer is molten before process is started.

4, Electrical house

The tip of the transducer can endure high temperature, but the shell (electrical house) only endure temperature lower than 80 $^{\circ}$ C, so it should place in the room temperature. It can benefit for the accuracy and natural life of the transducer if you keep the shell from the high temperature.


5, Overload effect

During the course of pressure measuring and controlling, it is better to make sure the transducer within the rated pressure, too long time overload the pressure will affect the accuracy and natural life of transducer, although the transducer own determinate overload ability.

6, Wiring

Use shielded cable, attach cable shield to ground at one end only. In order to prevent the jamming.

Select correct installation



Melt pressure transmitter



Wiring diagram

Output	Function	Color	5PIN
0/5V, 0/10V;	Signal +	Blue	1
	Excitation +	Red	2
	Signal -	White	3
	Excitation -	Yellow	4
	Calibration	Black	5
Output	Function	Color	5PIN
	Signal+	Blue	1
1/00 1	Excitation+	Red	2
4/20mA	Calibration	Yellow	4
	Calibration	Black	5
Output	Function	Color	6PIN
	Signal +	Blue	Α
	Signal -	Green	В
	Excitation +	Red	С
0-5V;0-10V;	Excitation -	Yellow	D
	Calibration	Brown	E
	Calibration	Black	F
Output	Function	Color	6PIN
	E+/ S+	Red	Α
4.00	E-/ S-	Blue	В
4-20mA	Calibration	Yellow	E
	Calibration	Black	F

Shanghai Zhaohui Pressure Apparatus Co., Ltd

5-6F No.8 Building No.115 ,Lane 1276 Nanle Road Songjiang District Shanghai 201600 China Tel:+86-21-51691919 67755189 Fax:+86-21-67755185 E-mail: info@zhyqsensor.com Ex www.zhygsensor.com



Page 4 of 4

ZHYQ sensor & control